




INSTRUCTION MANUAL

Thermoelectric Cooler



Thank you very much for buying this product. Before using your new refrigerator, please read this user manual to ensure that you gain the maximum benefit from it.

IMPORTANT SAFETY INSTRUCTIONS



To reduce the risk of fire, electrical shock, or injury when using your appliance, follow these basic precautions:

•Before using the appliance, please read this user manual to ensure that you gain the maximum benefit from it.

WARNING:

- 1) This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 2) Children should be supervised to ensure that they do not play with the appliance.
- 3) This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 4) If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 5) To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.
- 6) When positioning the appliance, ensure the supply cord is not trapped or damaged.
- 7) Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- 8) Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- 9) Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- 10) Do not damage the refrigerant circuit.
- 11) Do not use electrical appliances inside the drink storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- 12) Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- 13) This appliance is intended to be used in household and similar applications such as
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses and by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments;
 - catering and similar non-retail applications.
- 14) Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.
- 15) To avoid contamination of drink, please respect the following instructions:
 - Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
 - Clean regularly surfaces that can come in contact with drink and accessible drainage systems.
 - Clean water tanks if they have not been used for 48 h; flush the water system connected to a water supply if water has not been drawn for 5 days.
 - If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.
- 16) NOT suitable for camping use
 - the appliance shall not be exposed to rain

-WARNING: Risk of child entrapment. Before you throw away your old refrigerator or freezer:

-Take off the doors.

-Leave the shelves in place so that children may not easily climb inside.

-WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

-WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

-WARNING: Do not damage the refrigerant circuit.

-WARNING: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

• Note: This appliance contains flammable foaming agent cyclopentane.

Please avoid contact fire when you transport and use it.

Please ask professional for servicing when the machine broke down.

Please send it to your local appointed disposal station when you discard it.

-Save these instructions-

APPLIANCE SAFETY

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the Safety Alert Symbol. This symbol alerts you to potential hazards that can kill or injure you and others.

All safety messages will follow the Safety Alert Symbol and either the words "DANGER", "WARNING" or "CAUTION".



Danger means that failure to heed this safety statement may result in severe personal injury or death.



Warning means that failure to heed this safety statement may result in extensive product damage, serious personal injury, or death.



Caution means that failure to heed this safety statement may result in minor or moderate personal injury, or property or equipment damage.

All safety messages will alert you to what the potential hazard is, tell you how to reduce the chance of injury and let you know what can happen if the instructions are not followed





PROP. 65 WARNING FOR CALIFORNIA RESIDENTS

WARNING:

Cancer And Reproductive Harm

www.p65warnings.ca.gov

• INDICATION OF PARTS



1.	Cabinet	6.	Leveling legs
2.	Shelf	7.	Upper Door Hinge / Cover
3.	Cold sink fan	8.	Door
4.	Cold sink Fan Cover	9.	Gasket
5.	Ventilation Holes	10.	Bottom hinge

• TEMPERATURE CONTROL

It is recommended you install the Chiller in a place where the ambient temperature is between 16°-32°C/61°-90°F. If the ambient temperature is above or below recommended temperatures, the performance of the unit may be affected. For example, placing your unit in extreme cold or hot conditions may cause interior temperatures to fluctuate. The range of (8-18°C/46-64°F) may not be reached.

Temperature Ranges For Your Cooler

Temperature Range	8-18°C	46-64°F
-------------------	--------	---------




CONTROL PANEL




You can select temperature display setting from Fahrenheit to Celsius degree by pushing this button for two seconds. Fahrenheit or Celsius degrees indicator will appear in white color in the LED temperature display window with blue background.







• Temperature control

- You can turn the interior light ON or OFF by pushing the  button once. The light will be turned off automatically if it remains ON for 10 minutes. You have to push the  button again and the light will turn back on.
- You can select temperature display setting from Celsius to Fahrenheit degree by pushing the  button for 2 seconds.

1. Your Cooler has been equipped with an "automatic" control panel lock, that will activate 20 seconds after the last time a button has been touched.

Push the  button for 2 seconds to unlock the control panel. You will hear a "BEEP" sound to alert you that the control is now active.

2. You can set the temperature as you desire by pushing the  or  button on the control panel. The temperature that you desire to set will increase 1°C if you push the  button once, on the contrary the temperature will decrease 1°C if you push the  button once.

NOTE:


When you use the cooler for the first time or restart the cooler after having been shut off for a long time, there could be a few degrees variance between the temperature you select and the one indicated on the LED readout. This is normal and it is due to the length of the activation time. Once the cooler is running for a few hours everything will be back to normal.

➤ Storage Capacity

Many bottles may differ in size and dimensions. As such the actual number of bottles you may be able to store may vary. Bottle capacities are approximate maximums when storing traditional Bordeaux 750ml bottles and include bulk storage.


➤ Interior Light

You can turn the interior light ON or OFF by pushing the button marked with the "Light" symbol. 


The light will be turned off automatically if it remains ON for 10 minutes. You have to push the button marked with the "Light" symbol  again and the light will turn back on

• ELECTRIC DIAGRAM

BCW-18A



BCW-36A



• INSTRUCTION FOR USE

1,Note

- 1,1: Position your refrigerator so that the plug is accessible.
- 1,2: Keep your refrigerator out of direct sunlight.
- 1,3: Do not place next to heat generating appliance.
- 1,4: Do not place directly on the ground. Provide suitable stand.

2,Very important

- 2,1: The refrigerator will have better performance at ambient of 16-32 degree; We suggest the refrigerator be powered off if the ambient temperature is lower than 10 degree.
- 2,2: After plugging the appliance, allow the unit to cool down for 2-3 hours before placing beverage into the refrigerator compartment.
- 2,3: Ventilation is very important for this kind thermoelectric refrigerator; The inside PCB will be broken easily if the ventilation is bad; It will also reduce the life of the refrigerator.
- 2,4: The refrigerator applies automatic defrosting system, so there is no need to defrost it manually.


3,Power supply

- 3,1: The refrigerator must be connected to a properly earthed socket in line with relevant valid country regulations before operating;
- 3,2: Check the data label (which is on the side of the refrigerator) for voltage and frequency corresponds to your local one; If not, don't plug your cable into the socket;

• VENTILATION

When putting a TE cooler, ventilation should be considered seriously, please refer to the following:

- 1, there should be left at least 12 inch³ for ventilation
- 2, the distance between wall and cooler side should be at least 1inch
- 3, the back should be left at least 2inch for air flowing
- 4, air passing through must not be preheated
- 5, entire cooling system should be considered in the ventilation



• TROUBLE SHOOTING GUILDS

Failure: no cooling

Possible reason	Action
No power	Check the electricity supply, or change a new plug
PCB broken	Replace a new PCB
Fan broken	Replace a new fan
Leakage	Replace a new heat pump
Cooling module broken	Replace a new cooling module with silicone

Failure: poor cooling performance

Possible reason	Action
High ambient temperature	The room temperature is hotter than normal
Poor instruction	The door is opened too often
Poor ventilation	Install cooler according to our ventilation instruction
Poor gasket	Replace a new door gaske
Poor silicone	Change the silicone on the surface of the cooling module

Failure: noisy

Possible reason	Action
Dust	Clean the dust from the fan
Fan broken	Change to a new fan
Poor heat pump	Replace a new heat pump

Failure: frost or ice inside minibar

Possible reason	Action
Poor heat pump	Stop working for at least one hour, then restart it
Low ambient temperature	Adjust the air-conditioner to be around 25degree

• TECHNICAL DATA

Model No.	BCW-18A	BCW-36A
Net Capacity (liters)	17L	34L
Voltage (V)	AC 115V	
Frequency (Hz)	60Hz	
Rated Power (W)	58W	65W
Dimension (mm/inch)	265X515X393mm /10.4X20.3X15.5inch	265X515X645mm /10.4X20.3X25.4inch
Packing (mm/inch)	334X580X456mm /13.1X22.8X18inch	356X593X720mm /14X23.3X28.3inch
Net Weight (kg/lbs)	9.6kg/20.7lbs	13.5kg/ 29.8lbs

Correct disposal of this product



This symbol on the product, or in its packaging, indicates that this product may not be treated as household waste. Instead, it should be taken to the appropriate waste collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by the inappropriate waste handling of this product. For more detailed information about the recycling of this product, please contact your local council, your household waste disposal service, or the shop where you purchased the product.

If have any after-sales questions, pls contact below email address:
kingchiiofficial@outlook.com